

Experiment 5

Student Name: Praduman Kumar UID: 20BCS9446

Branch: CSE Section/Group: DM714-A

Semester: 6

Subject Name: IOT Lab Subject Code: 20CSP-358

1. Aim: To measure the distance of an object using an ultrasonic sensor.

2. Components Required:

- Arduino Uno R3 board
- Ultrasonic sensor (HC-SR04)
- Breadboard
- 4x Jumper Wires

3. Theory:

Ultrasonic Sensor:

An ultrasonic Sensor is a device used to measure the distance between the sensor and an object without physical contact. This device works based on time-to-distance conversion.

Working Principle:

We know that the speed of sound in air is nearly 344 m/s,

Using these parameters, we can calculate the distance traveled by the sound wave.

Formula: Distance = Speed * Time

4. Script:

```
long duration,distance;
void setup() {
   // put your setup code here, to run once:
   Serial.begin(9600);
```

```
pinMode(9,0UTPUT);
pinMode(4,INPUT);

void loop() {
   // put your main code here, to run repeatedly:
   digitalWrite(9,LOW);
   delayMicroseconds(10);
   digitalWrite(9,HIGH);
   delayMicroseconds(10);
   digitalWrite(9,LOW);
   duration=pulseIn(4,HIGH);
   distance=0.0343*duration/2;
   Serial.print("Distance:");
   Serial.println(distance);
}
```

5. Output:

Distance:10 Distance:10 Distance:11 Distance:11 Distance:11 Distance:11 Distance:11 Distance:12 Distance:12 Distance:13 Distance:14 Distance:14 Distance:14 Distance:15 Distance:16 Distance:16 Distance:16 Distance:17

6. Learning Outcome:

- Use of ultrasonic sensor
- Connection using breadboard
- Use of Arduino